

High Emission Density Thermionic Cathode

Arnold Shih, Code 6844

E-mail: shih@estd.nrl.navy.mil

Phone: (202)767-2260

FAX: (202)767-1280

Vacuum Electronics Branch

Naval Research Laboratory

Washington D.C. 20375

Workshop on Cathodes for Relativistic Electron Beams

May 10 - 11, 2001

High Emission Density Thermionic Cathode


- Historical development
- Properties of various cathodes
 - Emission capability
 - Operation: activation and poisoning
 - Life

OUTLINE

1. Work function : figure of merit
2. W and thoriated W cathodes
3. Oxide cathodes
4. Dispenser cathodes
5. Scandate cathodes

Work Function

Electron energy distribution in a metal



$$\Phi = E_{vac} - E_f$$

Richardson equation

$$J = AT^2 e^{-\Phi / kT}$$

$$A = 120 \text{ A/cm}^2 \text{ K}$$

Φ (eV)	T (K)	J (A/cm ²)
4.6	2600	1
4.6	2500	0.4
3.6	2500	41

Φ about 4.6 eV for W

Thoriated Tungsten

Thoriated Tungsten (Th-W):

A small percentage of thoria in W .


Thorium diffuses to the surface of the tungsten, and reduces the work function.

Carburization reduces the evaporation rate of the thorium.

	A_o	Φ_o
Th-W	4	2.65

Reference data for engineers: Radio, Electronics, Computer & Communications 8th Edition, p16-3, ed. M. Van Valkenburg, Newnes Press, Boston MA, 1993

Life Expectancy for a Switch Tube with a Th-W Cathode



T.E. Yingst, et al, Proc. IEEE, March 1973

The Relation of Φ_0 to Φ

Work function determination using Richardson plot yields Φ_0 .

Φ_0 is the temperature-independent part of Φ .

$$\text{i.e. } \Phi = \Phi_0 + c T$$

Re-write the Richardson equation,

$$\begin{aligned} J &= AT^2 \exp (- \Phi_0 + c T) / \kappa T \\ &= [A \exp (- c / \kappa)] T^2 \exp (- \Phi_0 / \kappa T) \end{aligned}$$

For Th-W:

$$\Phi_0 = 2.65$$

$$A_0 = [120 \exp (- c / \kappa)] = 4$$

or equivalently


$$\Phi = 2.65 + 2.9 \times 10^{-4} T$$

	A_0	Φ_0
Th-W	4	2.65

	T	Φ	J(A/cm ²)
Th-W	1950K	3.22	2.2
	2150K	3.27	12.0

Oxide Cathodes

	Φ (eV)	T (K)	J (A/cm ²)
W	4.6	2608	1
Th-W	3.2	1870	1
Oxide	1.5	942	1



BaO, SrO, CaO
Standard ASTM mixture
49%, 44%, 7% (atomic %)

Nickel substrate:

Active Ni, Ni with impurities such as W

$$\Phi = 1.5 \text{ eV}$$

Passive Ni, Ni without active impurity

$$\Phi = 1.85 \text{ eV}$$

Preparation and Processing of Oxide Cathodes

Sprayed method:


BaCO_3 , CaCO_3 and SrCO_3 are dissolved in organic solvent. After mixing thoroughly, the solution is sprayed onto nickel substrates.

Applied method (Sarong cathode)

BaCO_3 , CaCO_3 and SrCO_3 in organic binder forms a self-supporting sheet. Disks are cut from the sheet and applied to nickel substrate.


Potential problem:

Copious gas release during the initial cathode heating.




Melting temperature of the eutectic basic barium carbonate, $\text{BaO} \cdot \text{BaCO}_3$, occurs at about 900°C .

If this melting occurs CaO can segregate to the surface.



Work Function of Oxide Coating

Band diagram of BaO



Properties of Oxide Cathodes

Activation mechanism:

Generation of oxygen vacancies,

which shifts E_f from the intrinsic level to above the donor level

$\Phi = 1.5$ with active Ni substrate

$\Phi = 1.85$ with passive Ni substrate

Poisoning mechanism:


Annihilation of oxygen vacancies.

Poisoning gases: O_2 , CO_2 , H_2O and S.

Disadvantage of oxide cathodes:

- Not robust against residual gas poisoning.
- Coating flakes off after air exposure.
- Low D.C. emission, $\leq 1 \text{ A/cm}^2$.

Standard Dispenser Cathodes



Impregnant:


$4\text{BaO}, \text{CaO}, \text{Al}_2\text{O}_3$: [411], S-type

$5\text{BaO}, 3\text{CaO}, 2\text{Al}_2\text{O}_3$: [532], B-type

W provides the electrical conductivity.


BaO lowers Φ .

Work Function of a Dispenser Cathode



Cathode Surface Changes with Life

Cross-sectional view



Early in life, almost a full layer of Ba and O on the cathode surface.

During operation, desorption of Ba occurs, but a supply of Ba from the pores maintains a full coverage on the surface.

Impregnants near the pore end depletes during life, resulting in low surface Ba coverage and poor emission.

Properties of Dispenser Cathodes

Cathode poisoning:

CO₂, O₂ or H₂O adsorption reduces dipole effect
CO, CH₄, H₂ or N₂ adsorption does no harm,
but C residue poisons cathodes.

Reactivation from poisoning:

Thermal desorption of the poisoning gases.
Impregnant replenishes the surface Ba.

Compared to oxide cathodes:

More robust against gas poisoning.
Reusable after air exposures.
No DC emission limitation.
Higher work function.

	Φ (eV)	T (J =1 A/cm ²)
Oxide	1.5	942 K
Standard	2.1	1277 K
Os-coated	1.95	1194 K

Modification of Dispenser Cathodes

Coating: Strengthening the dipole

	Φ (eV)
Os-coating (M-type)	1.95
Os-W alloy-coating	~1.85
Ir-W alloy-coating	~1.85


Structure: Improve life or uniformity

Reservoir of Ba: **RV cathodes**


Long life

Controlled pores: **CPD cathodes**

Uniform emission



Trade-off between life and J




A.S.Gilmour, "Microwave Tubes", p132, (1986) Artech House, Inc.

Life test at very high J :

B-cathode: 45 A/cm^2 , 50 hours at 1620K, LLNL

R.E.Thomas et al, IEEE Trans on Electron Devices 37,no.3 (1990) 850.

Historical Development of Thermionic Cathode Emission Capability



	Φ
Standard dispenser	2.15 eV
M-type	1.95 eV
Optimum Alloy	1.85 eV
the best Scandate	1.47 eV

**Philips Research Lab claims:
400 A/cm² at 1300 K**

**Emission capability of a cathode with
 $\Phi = 1.47$ eV**

T (K)	T(°C)	J (A/cm ²)
1300	1030	400
1200	930	115
1100	830	26
1000	730	4.6

Scandate Cathodes Are Not Yet Available

Practical issues:

Unavailable commercially.

Fabrication technique needs to be developed.


Philips Research Lab. Provided little information.

Fundamental issues:


- 1. Robustness in practical environment.**
- 2. Emission uniformity.**

Slow Emission Recovery from Ion Beam Damage

Cathode in Tube Environment:



Ion Bombardment Removes Sc
⇒ Sc Needs to be Replenished



Scandate Emission Characteristics

Dispenser Cathodes (e.g. M-Type):


- Observe emission “saturation”
- Surface emission model (uniform ϕ)

Scandate Cathodes

- Emission continues to rise
- Emission model: unknown



Two Possible Models:

1. Semiconductor Emission Model
→ Uniform emission
2. “Patchy” Surface Emission Model
→ Higher J but non-uniform emission



Emission Uniformity Measurement Technique

Scanning Anode Probe



Emission Mapping

Fabrication Methods of Scandate Cathode

Scandate cathode types J ($T=1300\text{ K}$)

Pressed W + $\text{Ba}_3\text{Sc}_4\text{O}_9$ 5 - 10 A/cm^2

Sc in the impregnant 20 A/cm^2

Top-layer types

Mixed powder 100 A/cm^2

Sputtered 35 - 80 A/cm^2

Pulsed Laser Deposition
(or Laser Ablation) 400 A/cm^2

